

ImpressArt®

"Pi(e) for Days" – Food Sign Marker

Skill Level: Easy

Tools & Supplies

- Ergo-Angle™ Metal Stamping Hammer
- Steel Block
- Stamp Enamel Marker™
- Stamp Guides™
- Juniper™ Letter Set, Lowercase & Numbers, 3mm
- Fun Star Design Stamp, 3mm
- Food Sign Marker w/ Flourish Design, Aluminum
- Polishing Cloth, Paper Towel, or Clean Rag



STEP 1

Place food sign marker on stamping block. Secure straight stamp guide on food sign marker. Use guide marks to evenly space out letters and align stamp impressions.

TIP: Use stamp tape to secure the food sign marker to the stamping block so it doesn't move while stamping.

TIP: Write desired message directly onto the stamp guide and utilize the guideline marks for spacing.

STEP 2

Place stamp on blank above the corresponding mark on the stamp guide. Lightly drag stamp towards the guide until the stamp catches the edge of the guide. Strike the stamp once with medium force using Metal Stamping Hammer. Repeat to complete desired word.

TIP: If the stamp has an ImpressArt logo, make sure it is facing you so that the impression is stamped in the correct direction.

TIP: Slightly tilt the stamp towards you while dragging the stamp towards the guide. Make sure you hold the stamp flat and firmly in place before striking the stamp.

STEP 3

After stamping the first line, move the straight stamp guide down and repeat the technique to finishing stamping any additional lines.

TIP: If stamp guide becomes unusable due to rips or markings, then complete project with a new straight stamp guide

STEP 4

Highlight impressions and flourish design with Stamp Enamel Marker. Wait 3-5 minutes and then wipe away excess from the surface of the food sign marker.